

Perfect Protection
Locpro

My beloved family, my sweet home
Your choice protects Belongings.

Digital Doorlock K300 Series



K300B3

K300B3C



Smart Function! Easy open! Digital Doorlock K300 Series

- Smart touch**
 - Sensible LED Blue Lighting
 - High Sensitive Touch Pad
- Strong Durability**
 - Diecasting Material
 - Front One-Piece Touch Screen
- Fire Detection**
 - Fireproof Structure Design
 - High Temperature Alarm System
- Smart Function**
 - Passcode Hide Feature
 - One-Touch Anti-Panic



More Smart! More Safe!
Simple & Dynamic Design!

Locpro

Specification



• K300 Series

Type	2way : Passcode, RF Tag 3way : Passcode, RF Tag & Mechanical Key
Weight	3.1kg (Including package)
Operating Temperature	-20°C ~ 60°C
Dimension	Outbody 80(W) x 315(H) x 29(D) Inbody 82(W) x 315(H) x 31(D)
Emergency Battery	Alkaline 9V, 6LF22(Optional)
Color	Chrome Silver, Champagne Gold

• K300F Series

Type	3way : Passcode, RF Tag, Fingerprint 4way : Passcode, RF Tag, Fingerprint & Mechanical Key
Weight	3.1kg (Including package)
Operating Temperature	-20°C ~ 60°C
Dimension	Outbody 80(W) x 315(H) x 29(D) Inbody 82(W) x 315(H) x 31(D)
Emergency Battery	Alkaline 9V, 6LF22(Optional)
Color	Chrome Silver, Champagne Gold


- Fire Detection Function**
In case of sensing high temperature over 60°C, it alarms and activates door-open function.
- Prank Prevention Function**
Incorrectly entering the passcode the five times or more, the doorlock does not operate for 3 minutes.
- Easy installation without additional hole.**
Not necessary to drill additional hole, install doorlock just using by existing hole on the door.
- Passcode Hide Function**
Use the fake number and the actual passcode together whenever there is any chance of exposing the passcode to others.
- Door Open by Wireless Connect (Option)**
Locpro Doorlock can connect home network system to control the door.

- Anti-Panic of One-touch way**
In the event of an emergency, such as a fire, the anti-panic feature enables residents a quick and safe evacuation by pushing the handle down.
- Smart Touch Pad**
With the sensible LED and high-quality touch screen, the key pad cover can be utilized easily without having to open it. Every time the user touch the key, it blinks.
- Durability of Strong Material**
Considering durability and safety the best, it uses the Diecasting material resistant to fire or physical force.
- Fire Detection Function**
In case of sensing high temperature over 60°C, it alarms and activates door-open function.
- Prevention of electronic shock & static**
To prevent illegal entrance using the electric & electronic shock, the superior circuit blocks the impact.

● K300B3. K300F 系列




一、密碼設定




1. 打開電池盒後在左下角有『S』按下設定鍵。
2. 按密碼設定 4-13 碼。
3. 再按『*』鍵，即設定完成。

二、卡片設定




1. 打開電池盒後在左下角有『S』按下設定鍵。
2. 用 RF 感應卡或(無晶片)悠遊卡，在感應處感應，最多可以設定 50 張。
3. 再按『S』鍵，即設定完成。

三、指紋設定




1. 打開電池盒後在左下角有『S』按下設定鍵。
2. 把要設定的手指指紋，放在指紋感應處，連續 4 次，即可完成。
3. 再按『S』鍵，即設定完成。 PS:可設定 100 枚指紋。

四、門後開鎖方式




1. 於電子鎖背面按『OPEN』鍵。
2. 或 手把下壓開門。

五、門前開鎖方式




- 1.輸入密碼。
- 2.卡片感應。
- 3.鑰匙開鎖。
- 4.指紋感應。

六、自動/手動上鎖方式



- 1.打開電池盒。
- 2.選至『A』為自動上鎖。
- 3.或選至『M』為手動上鎖。

七、刪除所有設定方式



- 1.打開電池盒後在左下角有『S』按下設定鍵。
- 2.按『0』設定鍵。
- 3.按『S』設定鍵。
- 4.刪除所有卡片、及指紋設定。

*請定期更換電池，以免電池漏液，造成機板損壞。

*請使用 3 號鹼性電池。

*有任何問題，歡迎來電洽詢：



飛波電子股份有限公司
FEI PO ELECTRONICS CO.,LTD
地址:新北市中和區板南路671號12樓

TEL:02-8221-5868
FAX:02-8228-6396
<http://www.feipo.com.tw>
E-MAIL: david@feipo.com.tw